


## No sound or volume controls with the X209-WRA



In the event there is no sound or the volume controls on the unit and the steering wheel controls do not work use the following steps to make sure External Audio Processor is set to the off position.

*When this setting is "On," the Volume level is fixed at 10. Also, Balance/Fader/Subwoofer Level/Subwoofer Phase/Bass/Treble/MX HD/EQ Presets/Dual HD EQ/X-Over/Time Correction/Defeat/Phone Speaker/Default Sound Settings are set to "Off" or "Flat" and cannot be adjusted.*

Select: (MENU) (SET UP) (SYSTEM) (EXTERNAL ACCESSORIES)  
Make sure (EXTERNAL AUDIO PROCESSOR) is set to off

