


SETTING THE STAY ON MODE FOR CDE-164bt , CDE-154bt & CDE-153bt



- 1: Press and hold setup button for 3 seconds to enter setup menu
- 2: Rotate volume knob to select general and press enter
- 3: Rotate volume knob to select STAY ON and press enter
- 4: Rotate volume knob to select STAY ON time 5 MIN / 15 MIN / 30 MIN
- 5: Press and hold setup button for 3 seconds again to exit out of menu

Once the Stay on time has been selected the music will be paused after the ignition key is turned off (ACC OFF) at the same time the prompt ( PRESS PRESET 6 TO STAY ON ) will scroll once. Press 6 within 15 seconds to continue enjoying music for the selected time period. If 6 is not pressed the unit will power off within 15 seconds.