

Cannot control DVD player properly

Rating: Unrated | Last Updated: Sat, Oct 14, 2017 at 12:56 AM

1. DVD has not been set in the setup menu:

Ensure DVD is ON in HDMI SETUP menu

2. HDMI box has not been set in the SETUP menu:

Ensure DVD is ON in HDMI SETUP menu and remote loop was cut on wire harness

Posted by: [Alpine KB](#) - Sat, Oct 14, 2017 at 12:53 AM. This article has been viewed 4194 times.

Online URL: </article/cannot-control-dvd-player-properly.html>